



Steps for Installation w/ Supervisor on Site

STEP 1 Needs to be done before Supervisor is on site.

Excavate the area where the equipment will be installed.

- Area will need to be 12" below finished grade.
- Slope will be necessary if soil will not drain well- Area size will be determined by Miracle Representative

Get all equipment on site and remove all packaging.

STEP 3 *Done with Supervisor on site.*

Layout footings from diagram sent with the equipment from Miracle.

Attach VersaLoc collars to the posts w/ the correct # of attachments

Start to pre- assemble equipment.

Every bolt from here on will be tightened only hand tight.

STEP 4

Drill footing holes and set elevations.

Layout equipment where it is to be assembled

Drill out deck holes for deck brackets

STEP 5

Start assembling equipment

- deck and deck posts
- railings, bridges and tubes
- slides and climbers

STEP 6

Plum decks to level

Re- tighten all bolts

Set all set screws in clamps

STEP 7

Pour concrete and re- plum for level and check all connection

STEP 8

Cut off all bolts that are a protrusion

File bolts that have rough edges

File off all rough edges from decks

STEP 9 and 10

Rest, clean up and keep the children off the equipment for 72 hours