



## **TOOLS AND EQUIPMENT NEEDED FOR SUPERVISED INSTALLATION!!!**

Bobcat with auger (15" or 16" bit)  
Blocking to support the slides  
A few Allen wrench sets 3/16" - 3/8"  
Cordless Drills 1/2" & 3/8" ( 2 of each)  
Drill bits 1/16" - 9/16"  
5/8" treated plywood cut in 10" square (for post supports)  
Transit  
4' level  
Socket set 3/8" - 3/4" & 1/4" - 5/16"  
Screw drivers (regular and Philips)  
Wrenches 7/16" - 3/4"  
6' Pry bar (for leveling posts and slides)  
Rubber mallet  
Step ladder  
Electrical Source  
Shovels  
Electric Impact Wrench  
Set of taps for threaded holes- 3/8", 7/16" & 1/2"

Concrete for footings  
Water for mixing concrete  
Mixing hoe for concrete  
Wheelbarrows, at least 2